

# HIGH-FREQUENCY 99-CHANNEL TRANSMITTER

## # 1250 - QUICK START GUIDE



1. Enter the selected channel using the number keypad.
  - Indicator will flash 1 time for the first digit and 2 times for the second digit.
2. Press the "FIRE LAST" button to configure channel and to fire.
  - Indicator will flash 3 times.
3. Pressing the "FIRE ALL" button will trigger all devices.
  - Indicator will flash 5 times.
4. Subsequent firings on the same channel can be done by simply pressing the "FIRE LAST" button.

Transmitter is powered by 2 AA batteries and housed in a weatherproof case.

